

AIRPORT LOCAL GUIDELINES

ISTANBUL ATATÜRK AIRPORT

ICAO CODE	LTBA
IATA CODE	ISL
IATA LEVEL	Level 2 (SMA)
Phone	0 (212) 463 77 77
E-mail	atarampkule@dhmi.gov.tr

PARKING COORDINATION PARAMETERS

GA/BA flights	Ground time is more than 24 hours => coordinate with Ramp					
Wingspan Category C &D (A320,B737, A310, B767 etc.)	For all requests => coordinate with Ramp					
Wingspan Category E (A333, A346, B742, B777 etc.)	For all requests => coordinate with Ramp					
Wingspan Category F (A4F, A388, B747, C5 etc.)	For all requests => coordinate with Ramp					
Paxflow capacity per hour (T60)	DOM			INT		
	ARR	DEP	TOTAL	ARR	DEP	TOTAL
	0	0	0	0	0	0
Parking Constraints	Limited parking area					
Prohibited service types	C, G, J, K, X*(see special conditions)					
Prohibited aircraft types	AN124, AN225, C5, A380, B747-800, B747-500, B747-600					
Special Condition	Closed to scheduled/unscheduled domestic and international commercial passenger flights and will only be available for cargo, maintenance/technical, general aviation, air taxi, business flights, for state aircraft and other flights permitted by Authority. Landing and take-off activities for training purposes including traffic patterns and instrument landings shall not be permitted. Aircraft types AN124, AN225, C5, A380, B747-800, B747-500, B747-600 are not allowed to land at the aerodrome (Except presidential aircraft and special permitted aircraft) * All kinds of technical landing and divert flights that have not received permission from the aerodrome authority shall not be allowed for landing/take-off, and FPL acceptance shall not be made.					
Runway capacity per hour (R60)	ARR		DEP		TOTAL	
0	5		5		10	
1	5		5		10	
2	5		5		10	
3	5		5		10	
4	5		5		10	
5	5		5		10	
6	5		5		10	
7	5		5		10	
8	5		5		10	
9	5		5		10	
10	5		5		10	
11	5		5		10	
12	5		5		10	
13	5		5		10	
14	5		5		10	
15	5		5		10	
16	5		5		10	
17	5		5		10	
18	5		5		10	
19	5		5		10	
20	5		5		10	
21	5		5		10	
22	5		5		10	
23	5		5		10	